

Note:  
Existing Fasteners That Are In The Same  
Area As The NuWall Panel Seam Must Be  
Removed. Do Not Remove Side Lap  
Fasteners From Existing Wall Panels.

