

PBU Fastener Location At Panel Ends



PBU Fastener Location
At Intermediate Supports



PBU Panel Sidelap