



## Moldings Catalog Siding

---

5975 chemin de la Savane, Saint-Hubert, QC J3Y 0X1  
T. 450 464-5486 | F. 450 464-4538  
[MACmetalarchitectural.com](http://MACmetalarchitectural.com)  
[info@macmetalarchitectural.com](mailto:info@macmetalarchitectural.com)


**MAC**  
METAL ARCHITECTURAL

May 2024




# Disposition of the moldings


The suggested dispositions will apply to all profiles




Starter strip




Vertical transition trim




Inside corner or QJ



Outside corner with Integrated J Trim




Outside corner with integrated J




Outside corner




Horizontal transition trim




Extended J trim




J trim



Drip flashing



Extended drip flashing



Double drip flashing

Approximate manufacturing tolerances :  
1/16" on all lengths  
1 degree on bend angles

## Harrywood PLUS, Harrywood Block, MS 14, Norwood & Norwood Mini Profiles

Variable = Degree or inch / mm Units = Inch and/or mm


All Trims come in a 10' length, 26 gauge

### Starting strip

The starting strip will be the first to be put in place at the beginning of the work to guide and secure the production of the project.


### No. M10SHWP (HWP, HW & HWB)

#### Starting strip




### No. M10S14 (MS 14)

#### Starting strip



### No. M10D (NW & NWM)

#### Starting strip




### Rear restraining bracket

The rear support bracket acts as a reinforcement support when installing on large surfaces.

### No. ABRA2 (HW)

#### Rear restraining bracket



## Harrywood PLUS, Harrywood Block, MS 14, Norwood & Norwood Mini Profiles

Variable = Degree or inch / mm Units = Inch and/or mm

All Trims come in a 10' length, 26 gauge

### J trim


The J trim is used on the sides and bottom of any opening. Available in several forms depending on the needs of the project:

The double J trim will be used when a stronger molding is required or to fill a spacing. Note that the entire piece is colored.

The extended J trim will be used to cover more surface as in the case of a window that is coming out of the wall.


### No. M01C (HWP,HW,HWB & MS 14)

Extended J trim  
(2 pieces)




### No. M01C (HWP,HW,HWB & MS 14)

J trim




### No. M01D (NW & NWM)


J trim



A




B




### No. M03D (NW & NWM)


Extended J trim  
(2 pieces)



A



B



# Molding & Flashing

## Harrywood PLUS, Harrywood Block, MS 14, Norwood & Norwood Mini Profiles


Variable = Degree or inch / mm Units = Inch and/or mm

All Trims come in a 10' length, 26 gauge


### Inside corner or QJ

The QJ molding has the same functions as the J trim but is used most frequently as an interior corner.

#### No. M22C (HWP,HW,HWB & MS 14) Inside corner or QJ



#### No. M22D (NW & NWM) Inside corner or QJ




### Drip flashing

It is important to use a drip flashing over any opening to drain water.


The double drip flashing will be used to fill a gap. Note that the entire piece is colored.

The extended drip flashing is chosen when a window or opening is too far towards the inside of the wall. Note that the entire piece is colored.


#### No. M50CD (HWP,HW,HWB, MS 14 & NW & NWM) Flashing drip




#### No. M53CD (HWP,HW,HWB, MS 14 & NW & NWM) Double flashing drip



#### No. M56CD (HWP,HW,HWB, MS 14 & NW & NWM) Extended drip flashing w/variable



#### No. M52CD (HWP,HW,HWB, MS 14 & NW & NWM) Flashing drip variable



# Molding & Flashing

## Harrywood PLUS, Harrywood Block, MS 14, Norwood & Norwood Mini Profiles

Variable = Degree or inch / mm Units = Inch and/or mm


All Trims come in a 10' length, 26 gauge

### Outside corner

The outside corner is used to cover the junction of two outgoing walls.


### No. M20D (NW & NWM)

Outside corner with integrated J trim



### No. M20C (HWP, HW, HWB & MS 14)

Outside corner (2 pieces)




Variable = Degree or inch / mm Units = Inch and/or mm

All Trims come in a 10' length, 26 gauge

## No. M12C (HWP,HW,HWB &amp; MS 14)


Vertical transition trim (2 pieces)

The horizontal transition molding can also be used as a floor slump.




## No. M13C (HWP,HW,HWB &amp; MS 14)

Horizontal transition trim (2 pieces)



## No. M13D (NW &amp; NWM)

Horizontal transition trim (2 pieces)



# Molding & Flashing

## Harrywood PLUS, Harrywood Block, MS 14, Norwood & Norwood Mini Profiles

Variable = Degree or inch / mm Units = Inch and/or mm

All Trims come in a 10' length, 26 gauge


### Transition trim

Used to create a transition between two sidings, to create a junction during the installation of a large surface of the same siding, or to mark the change between two materials.

The horizontal transition molding can also be used as a floor slump.

### No. M12D (NW & NWM)

Vertical transition trim (2 pieces)




### L trim

The L trim will be used to fill a gap or to create a transition space between two sidings.

### No. M14CD (HWP, HW, HWB, MS 14, NW & NWM)

L trim




### W Trim Outside Corner

The outside corner is used to cover the junction of two outgoing walls.

### No. MXXP (POL)

W Trim Outside Corner





## Polymac, Versa & Metal Block Profiles


Variable = Degree or inch / mm Units = Inch and/or mm

All Trims come in a 10' length, 26 gauge


### Starting strip

The starting strip will be the first to be put in place at the beginning of the work to guide and secure the production of the project.

#### No. M10G (VS, MB) Starting strip



#### No. M10P (POL) Starting strip




### J trim

The J trim is used on the sides and bottom of any opening. Available in several forms depending on the needs of the project:


The double J trim will be used when a stronger molding is required or to fill a spacing. Note that the entire piece is colored.

The Extended J trim will be used to cover more surface as in the case of a window that is coming out of the wall.


#### No. M01G (POL, VS, MB) J trim



#### No. M03G (POL, VS, MB) Extended J trim variable



#### No. M07GP (POL, VS, MB) J Trim (2 pieces)



## Polymac, Versa & Metal Block Profiles

Variable = Degree or inch / mm Units = Inch and/or mm


All Trims come in a 10' length, 26 gauge

### Outside corner

The outside corner is used to cover the junction of two outgoing walls.


#### No. M21G (POL, VS, MB)

Outside corner w/ integrated J Trim



#### No. M20G (POL, VS, MB)

Outside corner (2 pieces)




### L trim

The L trim will be used to fill a gap or to create a transition space between two sidings.

#### No. M14G (POL, VS, MB)

L trim



Variable = Degree or inch / mm Units = Inch and/or mm

All Trims come in a 10' length, 26 gauge

### Drip flashing


It is important to use a drip flashing over any opening to drain water.

The double drip flashing will be used to fill a gap. Note that the entire piece is colored.

The extended drip flashing is chosen when a window or opening is too far towards the inside of the wall. Note that the entire piece is colored.


### No. M50G (POL, VS, MB)

Drip flashing




### No. M51G (POL, VS, MB)

Drip flashing w/ 90 degree angle




### No. M52G (POL, VS, MB)

Drip flashing variable




### No. M53G (POL, VS, MB)

Double drip flashing




### No. M56G (POL, VS, MB)

Extended drip flashing w/ variable



### No. M55G (POL, VS, MB)

Drip flashing double variable



## Polymac, Versa & Metal Block Profiles

Variable = Degree or inch / mm Units = Inch and/or mm


All Trims come in a 10' length, 26 gauge

### T trim

#### No. M11G (POL, VS, MB)

##### T trim

We recommend installing T molding every 10 to 12 feet when installing the Versa profile.




### S trim clip

#### No. M16G (POL, VS, MB)

##### S trim clip

The S molding is recommended for horizontal installations; it acts as a bridging joint.




### Inside corner

#### No. M22G (POL, VS, MB)

##### Inside corner

The inside corner is used at the junction of two incoming walls.



## Polymac Profile

Variable = Degree or inch / mm Units = Inch and/or mm

All Trims come in a 10' length, 26 gauge


### U trim or fixation trim

U-molding or offset moldings are the fastening moldings used to install Polymac panels.

They act as fastening supports during panel installation.


#### No. M15P (POL)

U trim or fixation trim




#### No. M18P12 (POL)

Offset Molding 12 inches



#### No. M18P20 (POL)

Offset Molding 20 inches



### J Trim (Polymac)


The J trim is used on the sides and bottom of any opening. Available in several forms depending on the needs of the project:

The double J trim will be used when a stronger molding is required or to fill a spacing. Note that the entire piece is colored.

The Extended J trim will be used to cover more surface as in the case of a window that is coming out of the wall.

#### No. M01P (POL)

Finition J Trim





## MS 380 Corrugated Profiles

Variable = Degree or inch / mm Units = Inch and/or mm

All Trims come in a 10' length, 26 gauge

### J Trim


#### No. M01F (MS380)

J trim

The J trim is used on the sides and bottom of any opening. Available in several forms depending on the needs of the project:


The Double J Trim will be used when a stronger molding is required or to fill a spacing. Note that the entire piece is colored.

The Extended J Trim will be used to cover more surface as in the case of a window that is coming out of the wall.



#### No. M03F (MS380)

Extended J-trim variable (2 pieces)



## MS 380 Corrugated Profiles

Variable = Degree or inch / mm Units = Inch and/or mm


All Trims come in a 10' length, 26 gauge

### Outside corner

The outside corner is used to cover the junction of two outgoing walls.

#### No. M21F (MS380)

Outside corner w/ integrated J Trim




### Inside corner

The inside corner is used at the junction of two incoming walls.

#### No. M22F (MS380)

Inside corner



## MS 380 Corrugated Profiles

Variable = Degree or inch / mm Units = Inch and/or mm

All Trims come in a 10' length, 26 gauge

### Drip flashing


It is important to use a drip flashing over any opening to drain water.

The double drip flashing will be used to fill a gap. Note that the entire piece is colored.

The extended drip flashing is chosen when a window or opening is too far towards the inside of the wall. Note that the entire piece is colored.


### No. M50F (MS380)

Drip flashing




### No. M56F (MS380)

Extended drip flashing w/ variable



### No. M53F (MS380)

Double drip flashing



# Molding & Flashing

## MS 750 & MS 750 I Profiles

Variable = Degree or inch / mm Units = Inch and/or mm

All Trims come in a 10' length, 26 gauge

### J Trim


The J trim is used on the sides and bottom of any opening. Available in several forms depending on the needs of the project:

The Double J Trim will be used when a stronger molding is required or to fill a spacing. Note that the entire piece is colored.

The Extended J Trim will be used to cover more surface as in the case of a window that is coming out of the wall.


### No. M01E (MS750 & 750I)

#### J Trim



### No. M03E (MS750 & 750I)

#### Extended J Trim w/variable




### Outside corner

The outside corner is used to cover the junction of two outgoing walls.

### No. M21E (MS750 & 750I)

#### Outside corner w/ integrated J Trim



## MS 750 & MS 750 I Profiles

Variable = Degree or inch / mm Units = Inch and/or mm


All Trims come in a 10' length, 26 gauge

### Inside corner

The inside corner is used at the junction of two incoming walls

#### No. M22E (MS750 & 750I)

Inside corner



### Drip flashing


It is important to use a drip flashing over any opening to drain water.

The double drip flashing will be used to fill a gap. Note that the entire piece is colored.

The extended drip flashing is chosen when a window or opening is too far towards the inside of the wall. Note that the entire piece is colored.


#### No. M50E (MS750 & 750I)

Drip flashing




#### No. M53E (MS750 & 750I)

Double drip flashing



#### No. M56E (MS750 & 750I)

Extended drip flashing w/ variable





## Board and Batten, Reverse Board and Batten Profiles

Variable = Degree or inch / mm Units = Inch and/or mm


All Trims come in a 10' length, 26 gauge

### Starting strip

The starting strip will be the first to be put in place at the beginning of the work to guide and secure the production of the project.

### No. M17H (BB & RBB)

Bricks transition trim / Starter strip 3'' (2 parts)




### Batten trim filler

The finishing strip acts as a filler inside the molding. Ideal when the "batten" of the sheets do not end inside a molding. They will then come to fill the gap by giving the impression of a batten for a perfect finish.

### No. M06H (BB & RBB)

Batten trim filler



## Board and Batten, Reverse Board and Batten Profiles

Variable = Degree or inch / mm Units = Inch and/or mm

All Trims come in a 10' length, 26 gauge


### J Trim

The J trim is used on the sides and bottom of any opening. Available in several forms depending on the needs of the project:


The Double J Trim will be used when a stronger molding is required or to fill a spacing. Note that the entire piece is colored.

The Extended J Trim will be used to cover more surface as in the case of a window that is coming out of the wall.


**No. M01H (BB & RBB)**  
J trim 1 in




**No. M03H (BB & RBB)**  
Extended J Trim 1 in w/var





**No. M02H (BB & RBB)**  
Double J trim 1 in



**No. M05H (BB & RBB)**  
Extended J Trim 3 in w/var



**No. M04H (BB & RBB)**  
J trim 3 in (2 pieces)



## Board and Batten, Reverse Board and Batten Profiles

Variable = Degree or inch / mm Units = Inch and/or mm

All Trims come in a 10' length, 26 gauge

### Drip flashing


It is important to use a drip flashing over any opening to drain water.

The double drip flashing will be used to fill a gap. Note that the entire piece is colored.

The extended drip flashing is chosen when a window or opening is too far towards the inside of the wall. Note that the entire piece is colored.


### No. M51H.A (BB & RBB)

Drip flashina w/90° anale




### No. M53H.A (BB & RBB)

Double drip flashing




### No. M50H.A (BB & RBB)

Drip flashing



### No. M54H.A (BB & RBB)

Double drip flashing w/90 degrees angle



Variable = Degree or inch / mm Units = Inch and/or mm

All Trims come in a 10' length, 26 gauge

### Drip flashing


It is important to use a drip flashing over any opening to drain water.

The double drip flashing will be used to fill a gap. Note that the entire piece is colored.

The extended drip flashing is chosen when a window or opening is too far towards the inside of the wall. Note that the entire piece is colored.


### No. M56H.A (BB & RBB)

Extended drip flashing w/var



### No. M57H.A (BB & RBB)

Extended drip flashing w/90° angle




### Transition trim

Used to create a transition between two sidings, to create a junction during the installation of a large surface of the same siding, or to mark the change between two materials.

The horizontal transition molding can also be used as a floor slump.

### No. M17H (BB & RBB)

Bricks transition trim / Starter strip 3'' (2 parts)



## Board and Batten, Reverse Board and Batten Profiles

Variable = Degree or inch / mm Units = Inch and/or mm

All Trims come in a 10' length, 26 gauge


### Transition trim

Used to create a transition between two sidings, to create a junction during the installation of a large surface of the same siding, or to mark the change between two materials.

The horizontal transition molding can also be used as a floor slump.


#### No. M12H (BB & RBB)

Vertical transition trim (2 pieces)



#### No. M13H (BB & RBB)

Horizontal transition trim (2 pieces)





## Board and Batten, Reverse Board and Batten Profiles

Variable = Degree or inch / mm Units = Inch and/or mm


All Trims come in a 10' length, 26 gauge

### Inside corner

#### No. M22H (BB & RBB)

Inside Corner

The inside corner is used at the junction of two incoming walls.



### Outside corner

#### No. M21H (BB & RBB)

Outside corner w/ integrated J Trim

The outside corner is used to cover the junction of two outgoing walls.

